AIZAS **D**SUIQ





GL HAMBURG



THIS SUIT IS TO BE WORN WITH AN APPROVED **LIFEJACKET**

DONNING INSTRUCTIONS

- 1. Put the immersion suit out of the bag
- 2. Wear the suit as you would a pair of coveralls.
- 3. Pull hood up over head.
- 4. Fully close zipper & adjust ankle bands.
- 5. Close face flap.

CARE INSTRUCTIONS

- 1. DO NOT DRY CLEAN. Rinse with fresh water after each usage.
- 2. Let it drip dry completely before repacking.
- 3. Lubricate zipper with wax stick.
- 4. Leaving zipper of suit open, repack suit.

See information sheet for additional information.

IMPORTANT: It is recommended that the suit not be donned in the vessel's cabins but on a weather deck.

THE IMMERSION SUIT COMPLIES WITH SOLAS LSA CODE AND MSC.81(70) AS AMENDED



Address: Gounari 3, P.C 14531, Piraeus - Greece Tel.: +30 210 4226274, fax: +30 210 4226273, e-mail: info@lalizas.com www.lalizas.com